

PETZL

3 year guarantee

ASCENSION

B17L/B17R

BASIC

B18

(EN) Rope clamp**(FR) Bloqueur****(DE) Seilklemme****(IT) Bloccante****(ES) Bloqueador**

B17




136 g

B18



136 g




**Individually tested**PETZL
3 Cités 1054
38510 Crêttes
France
www.petzl.com/contactISO 9001
Copyright Petzl**WARNING****Activities involving the use of this equipment are inherently dangerous. You are responsible for your own actions and decisions.**

Before using this equipment, you must:


- Read and understand all Instructions for Use.
- Get specific training in its proper use.
- Become acquainted with its capabilities and limitations.
- Understand and accept the risks involved.

**FAILURE TO HEED ANY OF THESE WARNINGS MAY RESULT IN SEVERE INJURY OR DEATH.****Nomenclature of parts**

Rope (cable + sheath) ø 6-13 mm low stretch (EN 1891) or dynamic (EN 652)
 Corda (cabo + gaine) ø 6-13 mm estirável (EN 1891) ou dinâmica (EN 652)
 Seil (Kern + Mantel) ø 6-13 mm elastisch (EN 1891) oder dynamisch (EN 652)
 Corda (centro + capa) ø 6-13 mm elastică (EN 1891) u dinamică (EN 652)
 Cuerda (alma + funda) ø 6-13 mm elástica (EN 1891) o dinámica (EN 652)

**1. Installing the rope****3. Descent****2. Ascent**

4. Progression on rope
 without direct aid
 and from the structure



ACCIDENTS TO AVOID

FORWARD OF
 LIMBS AND
 TOOLS
 FROM THE
 ROPE

FORWARD OF
 LIMBS AND
 TOOLS
 FROM THE
 ROPE

FORWARD OF
 LIMBS AND
 TOOLS
 FROM THE
 ROPE



5. Mixed progression, structures and rope



6. Progression
 on a structure
 without direct aid
 from the rope :
 not to be done



7. Horizontal progression



8. Hoisting system

